



Installation Guide

ARK Flashing Tape

Wide Flashing Tape for Inside and Outside Wall Corners for Buildings.

Product Overview

ARK Flashing Tape provides reliable sealing for seams, tears, and holes in waterproofing and weather-resistive barriers. Its strong adhesive bonds securely to ARK membranes, creating a continuous protective barrier for long-lasting performance. Easy to install, it helps reduce water damage, improve energy efficiency, and enhance indoor comfort.

General Considerations

Start at the bottom of the structure to ensure proper shingling throughout the installation. Proper shingling is required to shed and prevent water from entering the wall system. Be sure to overlap the previously installed piece of Flashing Tape by at least 2".

The method in this bulletin depicts the Flashing Tape installed directly to the sheathing before the membrane is installed. Flashing Tape can also be installed after the membrane, but care must be taken if installed over the membrane, as the tape will bond almost instantly.

Protecting Inside Wall Corners with Flashing Tape

1. Cut the Flashing Tape to a manageable length.
2. Fold Flashing Tape in half lengthwise, apply pressure to create a sharp crease.
3. Starting at the bottom of the wall, place the fold flush against the inside corner with the release papers facing out.
4. Remove the release paper closest to the inside corner.
5. Working out from the corner, apply pressure and roll the tape outward to adhere smoothly—avoid wrinkles and fish mouths.
6. Remove the outside release paper and adhere the tape to the surface using firm hand pressure or a j-roller.
7. Remove the remaining release paper and apply using firm pressure or a j-roller.

Visit us at [arksynthetics.com](https://www.arksynthetics.com) for questions, call (778)3251557



8. Repeat steps 1-7 for the next length of Flashing Tape until reaching the top of the structure. Be sure the tape overlaps by at least 2".

Protecting Outside Wall Corners with Flashing Tape

1. Cut the Flashing Tape to a manageable length.
2. Fold Flashing Tape in half lengthwise, apply pressure to create a sharp crease.
3. Starting at the bottom of the wall, align the folded edge with the corner, release papers facing out.
4. Remove the release paper closest to the corner.
5. Working out from the corner, use firm hand pressure or a j-roller to roll the tape outward—avoid wrinkles and fish mouths.
6. Remove the outside release paper and adhere the tape to the surface.
7. Remove the remaining release paper and apply using firm hand pressure or a j-roller.
8. Repeat steps 1-7 for the next length of Flashing Tape until reaching the top of the structure. Be sure the tape overlaps by at least 2".

Maintenance & Warranty

ARK Flashing Tape do not need special maintenance after installed; Lifetime warranty from the day of installation if it is quality defects.

Remark:

Recommendations on methods, materials, and construction details are provided by Ark Synthetics based on current knowledge and experience. They serve as a general guide for designers, contractors, and manufacturers. Installation should also consider local conditions, project-specific requirements, and guidance from designers or other qualified professionals. For project assistance, contact info@arksynthetics.com

ARK SYNTHETICS INC.
2015 MAIN STREET
VANCOUVER, BC V5T 3C2 CANADA
+1 778-325-1557
info@arksynthetics.com

Visit us at arksynthetics.com for questions, call (778)3251557



www.arksynthetics.com

Pub. No. AS-36675. Printed in Canada. April 2025.

© 2025 Ark Synthetics Inc. All Rights Reserved.